

NO.M403001

W20xH22xD8 cm




NO.M403002

W20xH18xD13 cm




NO.M403003

W23xH16xD9 cm



NO.M403004

W25xH18xD12cm



NO.M403005

W14xH19.5xD14cm



高:19.5cm


宽:14cm

上宽:23.5cm/下宽14cm





NO.M403006

W22xH21xD15cm



NO.M403007

W18xH18xD11cm



NO.M403008

W25xH25xD10 cm



25cm

10cm

25cm




NO.M403009

W30xH34xD10 cm



NO.M403010

W15xH21xD8 cm



NO.M403011

W19.5xH21xD9.5 cm





NO.M403012

W17xH19xD6 cm



NO.M403013

W16xH19xD6cm



NO.M403014

W10xH18xD2cm



NO.M403015

W10.5xH17.5xD4cm



NO.M403016

W22.5xH15xD5cm



NO.M403017

W15xH13.5xD9.5cm



(手机仅为拍摄道具, 不在出售范围)



● 克莱因蓝



● 开心果白




● 草地绿



● 蜜桃粉



● 嫩芽绿



NO.M403018

W19xH17xD11cm



● 蜜桃粉



● 嫩芽绿



● 落叶黄



● 香芋紫



● 湖水绿



NO.M403019

W17xH19xD15cm



● 优雅黑



● 焦糖棕



● 花瓣白



NO.M403020

W29xH26xD12.5cm



● 优雅黑



○ 花瓣白



● 焦糖棕

